




SPRAY GUN RECOMENDATIONS





CLEAR		
		
Ø mm	psi	
WS-400 EVOTECH SUPERNOVA		
WS-400HD	1.3HD	25-28





BASECOAT		
		
Ø mm	psi	
LS-400 ENTECH/WS-400 EVOTECH SUPERNOVA		
LS-400-12ET	1.2 ET	22
WS-400-OBS	OBS	26.28



SEALER		
		
Ø mm	psi	
LPH-300-LV		
LPH-300-LV	1.8	18



SURFACER		
		
Ø mm	psi	
LPH-300-LV		
LPH-300-LV	1.8	16-18